

آموزش راه اندازي دانگل ISTARX99

منو وارد شده

دکمه MUTE را با سه بار عدد 999 وارد کنید

PACH:ENABLE

RS232 MODE : SDSMODE

SDS SAT LIST: انتخاب ماهواره شرینگ

[WWW.ISTARKOREA.COM](http://WWW.ISTARKOREA.COM)

---

# main menu



Installation



Service Organizing



STB Setting



STB Status



USB Menu



Ethernet Setting



CA Menu



Move



Select



Exit current menu



PIP Fun



www.istarkorea.com



Patch

Enable



RS232 Mode

Disable

Disable

Enable

**www.istarkorea.com**



Move



Change Setting



Finish



Exit current menu





Patch

Enable

RS232 Mode

Disable



**www.istarkorea.com**

U Disable

02 PC Sharing ECM

06 Twin Protocol

08 Ethernet Mode

09 SDS Mode [1.Def

16 SSSP



Move Change Setting Finish

Exit current menu



Patch

Enable

RS232 Mode

Disable



U Disable

02 PC Sharing ECM

06 Twin Protocol

08 Ethernet Mode

09 SDS Mode [1.Def

16 SSSP



[www.istarkorea.com](http://www.istarkorea.com)



Select



Move



Change Setting



Exit current menu





Patch

Enable

RS232 Mode

SDS Mode

SDS Sat List

Eutelsat W3A [7.0E]

Eutelsat W3A [7.0E]

Eutelsat W6 [21.6E]

ExpressAM22[53.0E]

HellasSat2 [39.0E]

NSS 6 [95.0E]

ASTRA2C [31.5E]

[www.istarkorea.com](http://www.istarkorea.com)



Move



Change Setting



Finish



Exit current menu

